

Calibration Supplies



CALIBRATION SUPPLIES

- Dry gas available in .038, .082, and .100 alcohol value
- 34 liter, 55 liter, and 108 liter sizes
- Use with all Intoximeter instruments
- Evidential quality

ALCOPRO
DRUG & ALCOHOL TESTING PRODUCTS

1-800-227-9890
www.alcopro.com

Calibration Supplies

Evidential, Convenient Calibration Standards

The larger 108 liter tanks offer the best value with enough gas to perform up to 500 accuracy checks. The smaller 34 liter tank fits into the padded carry case for the RBT IV and Alco-Sensor IV with memory while the 55 liter Tank fits beneath the keyboard of the RBT VXL, offering greater portability.

Regulator

The standard regulator uses a flow rate of 1.5 LPM (liter per minute), ideal for use with any model Alco-Sensor. The 6.0 LPM regulator creates a faster gas flow that will trigger an automatic sample when used with the Alco-Sensor FST. A gauge shows current pressure to indicate the amount of gas remaining. Regulators are a one-time purchase; when a tank is expired or empty, the operator removes the regulator from the old tank and installs it on the new tank. Regulators are hand tightened. They do not require a wrench to install or remove.

True-Cal II

The operator may use the optional True-Cal II device to interpret the true alcohol concentration of an alcohol gas tank. The True-Cal II measures barometric pressure to calculate the true alcohol reading of a tank at a given elevation. Day to day changes in barometric pressure may also cause the alcohol value of tanks to change very slightly. The operator presses the button, and the True-Cal II displays the calculated alcohol value for a tank at that location and moment. (Without the True-Cal II the operator consults an elevation table on the label of every tank to determine the expected alcohol value.)



REGULATOR

Compatible tanks: all 108, 55, and 30 liter tanks

Flow rate: 1.5 LPM and 6.0 LPM

Installation method: Hand Tightens

Measurement range: 0 - 1500 psi

TRUE-CAL II

Compatibility: Programmable to use with any Intoximeter tank

Power Supply: 1 AA alkaline battery, 15,000 operational hours

Attachment method: Velcro strap

Dimensions: 3.25" x 2.5" - 4 oz

CALIBRATION SUPPLIES

ITEM	DESCRIPTION	PRICE
324-04	Alcohol Gas Tank 108 liter (.038)	\$170.00
324-08	Alcohol Gas Tank 108 liter (.082)	\$170.00
324-10	Alcohol Gas Tank 108 liter (.100)	\$170.00
382-04	Alcohol Gas Tank 34 liter (.038)	\$138.50
382-08	Alcohol Gas Tank 34 liter (.082)	\$138.50
370-04	Alcohol Gas Tank 55 liter (.038)	\$149.00
328	Regulator, 1.5 lpm	\$112.00
328-6	Regulator, 6 lpm	\$124.50
329	True-Cal II	\$225.00

For Information & Orders Call: **1-800-227-9890**
 Order 24 Hours A Day At: www.alcopro.com
 Fax Orders To: **1-800-655-5834**

ALCOPRO
 DRUG & ALCOHOL TESTING PRODUCTS