



# ALCO-SENSOR RBT VXL

## Evidential Breath Alcohol Tester

### Evidential accuracy in the palm of your hand.

The Alco-Sensor RBT VXL is approved by the U.S. Dept. of Transportation as an evidential breath testing device and is widely used for DOT and non-DOT workplace testing. Easy-to-use and durable, the Alco-Sensor RBT VXL provides reliable results for a more accurate, more defensible testing program.

- Evidential accuracy exceeds +/- .005 at .100 BrAC
- Automatic breath sampling feature captures a deep lung breath sample
- Manual breath sampling is available in shy lung situations or when a subject is uncooperative
- Automatic :15 wait period countdown following a positive screening test result
- Programmed with DOT and NRC testing protocols
- Intuitive testing menus guide the operator through a test sequence, reducing operator errors
- Test subjects without being tethered to a printer for optimal mobility
- Stores thousands of test results in the internal memory

Items 215 and 217 come with DOT quick test and full data test modes, (Full data test collects: subject name, subject ID no., company name, BAT name, BAT ID no., reason for test data)

Item 217-DL is programmed with a DOT quick test mode only (Quick test mode collects: reason for test data)



**ALCOPRO**  
DRUG & ALCOHOL TESTING PRODUCTS

## SPECIFICATIONS

|                               |  |                               |   |
|-------------------------------|--|-------------------------------|---|
| <b>Sensor Type:</b>           | Electrochemical Oxidation (fuel cell)                                | <b>Calibration:</b>           | Microprocessor controlled using gas or wet bath simulator |
| <b>Measurement Range:</b>     | .000 - .040 BrAC   | <b>Memory:</b>                | More than 1,000 tests                                     |
| <b>Breath Sampling:</b>       | Automatic with Manual override                                       | <b>Print Capability:</b>      | Yes (with docking station and thermal printer)            |
| <b>Results Response Time:</b> | 3 - 5 sec. for negative results;<br>5 - 10 sec. for positive results | <b>Accuracy:</b>              | U.S. DOT approved for evidential use                      |
| <b>Power:</b>                 | 4 AA batteries (included)  | <b>Operating Temperature:</b> | -5° to 50° celcius  |
| <b>Test Modes:</b>            | Direct   | <b>Size:</b>                  | 14" x 14" x 5" (12 lbs in carry case)                     |
| <b>Warranty:</b>              | Two year parts and labor   | <b>Computer:</b>              | Yes with docking station and Accelerator software         |

### ALCO-SENSOR RBT VXL

| Item   | Standard Product  | Software           |
|--------|---|--------------------|
| 215-DL | Alco-Sensor VXL, thermal printer, keyboard, docking station, 100 mouthpieces, nylon case, printer paper, batteries, manual                                    | Data-Lite software |
| 215    | Alco-Sensor VXL, thermal printer, keyboard, docking station, 100 mouthpieces, nylon case, printer paper, batteries, manual                                    | Full data software |
| 217    | Alco-Sensor VXL, thermal printer, keyboard, docking station, 100 mouthpieces, 55 liter gas tank, tank regulator, nylon case, printer paper, batteries, manual | Full data software |

### RELATED ITEMS AND SUPPLIES

| Item   | Description                      |
|--------|----------------------------------|
| 380    | Alco-Sensor VXL mouthpiece       |
| 842    | TestSafe™ bacterial viral filter |
| 370-04 | Alcohol gas tank, 55L            |
| 328-06 | Regulator 1.5 LPM                |



Item 217

### A Few Good Reasons To Trust Us



**Same day shipping**  
Most orders placed before 2:00 pm EST ship same day.



**Knowledgeable Customer Support**  
Chat online or by phone.



**Trusted Supplier more than 35 years.**  
Supporting our customers since 1982.



**Largest inventory**  
We stock more, so you never run out.