



ALCO-SENSOR III

Evidential Breath Alcohol Tester

Evidential accuracy in the palm of your hand.

The Alco-Sensor III is approved by the U.S. Dept. of Transportation as an evidential breath testing device and is trusted worldwide by law enforcement, corrections and substance abuse professionals as a preliminary breath tester. Easy-to-use and durable, the Alco-Sensor III provides reliable results for a more accurate, more defensible testing program.

- Evidential accuracy exceeds +/- .005 at .100 BrAC
- Approved in most states as a preliminary breath tester (PBT)
- Test results display in seconds as a three-digit number
- Easy two button operation
- Intuitive testing menus guide the operator through a test sequence, reducing operator errors
- Re-display test results from the last test by pushing the READ button a second time
- Fuel cell detects alcohol only
- Mouthpiece ejector button



GSA *Advantage!*[®]

Available on GSA Advantage for eligible Federal agencies.

ALCOPRO
DRUG & ALCOHOL TESTING PRODUCTS

SPECIFICATIONS

Sensor Type:	Electrochemical Oxidation	Calibration:	Microprocessor controlled using gas or wet bath simulator
Measurement Range:	.000 - .040 BrAC	Memory:	Last test
Breath Sampling:	Manual	Print Capability:	No
Results Response Time:	5 - 10 sec. for negative results; 5-15 sec. for positive results	Accuracy:	U.S. DOT approved for evidential use
Power:	9-volt battery (included)	Operating Temperature:	0 - 40° celcius
Test Modes:	Direct	Size:	2" x 4.6" (6 oz)
Warranty:	One year parts and labor	View our device operation, calibration and accuracy check videos online	

ALCO-SENSOR III

Item	Standard Product	Intended Markets
204-LE	Alco-Sensor III, hard-shell case, 25 mouthpieces, battery, operator manual, calibration tool	Law enforcement, corrections
204-CAN	Alco-Sensor III, hard-shell case, 25 mouthpieces, battery, operator manual, calibration tool, mini alcohol gas can	Substance abuse treatment, schools/colleges, non-DOT workplace testing

RELATED ITEMS AND SUPPLIES

Item	Description
305	Alco-Sensor III mouthpiece
842	TestSafe™ bacterial viral filter
324	Alcohol gas tank, 105L
328-06	Regulator 1.5 LPM



A Few Good Reasons To Trust Us



Same day shipping
Most orders placed before 2:00 pm EST ship same day.



Knowledgeable Customer Support
Chat online or by phone.



Trusted Supplier more than 35 years.
Supporting our customers since 1982.



Largest inventory
We stock more, so you never run out.