



ALCO-SENSOR IV with Memory

Evidential Breath Alcohol Tester

Evidential accuracy in the palm of your hand.

The Alco-Sensor IV with Memory is approved by the U.S. Dept. of Transportation as an evidential breath testing device and is widely used for law enforcement and corrections programs. Easy-to-use and durable, the Alco-Sensor IV with Memory provides reliable results for a more accurate, more defensible testing program.

- Evidential accuracy exceeds +/- .005 at .100 BrAC
- Automatic breath sampling feature captures a deep lung breath sample
- Manual breath sampling is available in shy lung situations or when a subject is uncooperative
- Test results display in seconds as a three-digit number
- Intuitive testing menus guide the operator through a test sequence, reducing operator errors
- Stores more than 70 test results in the internal memory



ALCOPRO
DRUG & ALCOHOL TESTING PRODUCTS

SPECIFICATIONS

Sensor Type:	Electrochemical Oxidation (fuel cell)	Calibration:	Microprocessor controlled using gas or wet bath simulator
Measurement Range:	.000 - .040 BrAC	Memory:	More than 70 tests
Breath Sampling:	Automatic with Manual override	Print Capability:	Yes (thermal or slip printers)
Results Response Time:	5 - 10 sec. for negative results; 10 - 30 sec. for positive results	Accuracy:	U.S. DOT approved for evidential use
Power:	9-volt battery (included)	Operating Temperature:	0 - 40° celcius
Test Modes:	Direct	Size:	3" x 5" x 1" (11 oz)
Warranty:	One year parts and labor	Computer:	Yes with software

ALCO-SENSOR IV with Memory

Item	Standard Product	Intended Markets
206M-NON	Hard-shell case, 25 mouthpieces, battery, operator manual, calibration tool	Law enforcement, corrections
227-P-NON	Thermal printer, hard-shell case, 100 mouthpieces, printer paper, batteries, printer cables, operator manual, calibration tool	

RELATED ITEMS AND SUPPLIES

Item	Description
312	Alco-Sensor IV mouthpiece
842	TestSafe™ bacterial viral filter
382-08	Alcohol gas tank, 34L
328-06	Regulator 1.5 LPM



Item 206M-Non

A Few Good Reasons To Trust Us



Same day shipping

Most orders placed before 2:00 pm EST ship same day.



Knowledgeable Customer Support

Chat online or by phone.



Trusted Supplier more than 35 years.

Supporting our customers since 1982.



Largest inventory

We stock more, so you never run out.