



# ALCO-SENSOR III

## Evidential Breath Alcohol Tester

### Evidential accuracy in the palm of your hand.

The Alco-Sensor III is approved by the U.S. Dept. of Transportation as an evidential breath testing device and is trusted worldwide by law enforcement, corrections and substance abuse professionals as a preliminary breath tester. Easy-to-use and durable, the Alco-Sensor III provides reliable results for a more accurate, more defensible testing program.

- Evidential accuracy exceeds +/- .005 at .100 BrAC
- Approved in most states as a preliminary breath tester (PBT)
- Test results display in seconds as a three-digit number
- Easy two button operation
- Intuitive testing menus guide the operator through a test sequence, reducing operator errors
- Re-display test results from the last test by pushing the READ button a second time
- Fuel cell detects alcohol only
- Mouthpiece ejector button



# SPECIFICATIONS

<b>Sensor Type:</b>	Electrochemical Oxidation	<b>Calibration:</b>	Microprocessor controlled using gas or wet bath simulator
<b>Measurement Range:</b>	.000 - .040 BrAC	<b>Memory:</b>	Last test
<b>Breath Sampling:</b>	Manual	<b>Print Capability:</b>	No
<b>Results Response Time:</b>	5 - 10 sec. for negative results; 5-15 sec. for positive results	<b>Accuracy:</b>	U.S. DOT approved for evidential use
<b>Power:</b>	9-volt battery (included)	<b>Operating Temperature:</b>	0 - 40° celcius
<b>Test Modes:</b>	Direct	<b>Size:</b>	2" x 4.6" (6 oz)
<b>Warranty:</b>	One year parts and labor	View our device operation, calibration and accuracy check videos online	

## ALCO-SENSOR III

Item	Standard Product	Intended Markets
204-LE	Alco-Sensor III, hard-shell case, 25 mouthpieces, battery, operator manual, calibration tool	Law enforcement, corrections
204-CAN	Alco-Sensor III, hard-shell case, 25 mouthpieces, battery, operator manual, calibration tool, mini alcohol gas can	Substance abuse treatment, schools/colleges, non-DOT workplace testing

## RELATED ITEMS AND SUPPLIES

Item	Description
305	Alco-Sensor III mouthpiece
842	TestSafe™ bacterial viral filter
324	Alcohol gas tank, 105L
328-06	Regulator 1.5 LPM



## A Few Good Reasons To Trust Us



**Same day shipping**  
Most orders placed before 2:00 pm EST ship same day.



**Knowledgeable Customer Support**  
Chat online or by phone.



**Trusted Supplier more than 40 years.**  
Supporting our customers since 1982.



**Largest inventory**  
We stock more, so you never run out.